

## IN-SERIES TNC ADAPTERS


**T248CU-X\*\*\*\*\***  
TNC DOUBLE MALE



**T226CU-X\*\*\*\*\***  
TNC MALE TO TNC FEMALE



**T216CU-X\*\*\*\*\***  
TNC DOUBLE FEMALE



**T221CU-X\*\*\*\*\***  
TNC TRIPLE MALE




**T218CU-X\*\*\*\*\***  
TNC MALE TO  
TNC DOUBLE FEMALE




**T219CU-X\*\*\*\*\***  
TNC TRIPLE FEMALE




**T250CU-X\*\*\*\*\***  
TNC DOUBLE FEMALE  
BULKHEAD TYPE



**T394CU-XNGD\*\***  
TNC DOUBLE FMELAE  
BULKHEAD TYPE




**T422CU-XNGD\*\***  
TNC DOUBLE FEMALE  
BULKHEAD TYPE



**T217CU-X\*\*\*\*\***  
TNC MALE TO TNC FEMALE  
RIGHT ANGLE TYPE



**T421CU-XNGD\*\***  
TNC DOUBLE FEMALE



## BETWEEN SERIES TNC ADAPTERS (1)

**T223CU-X\*\*\*\*\***  
TNC MALE TO UHF MALE



**T252CU-X\*\*\*\*\***  
TNC MALE TO N MALE



**T228CU-X\*\*\*75**  
TNC MALE TO F MALE



**T224CU-X\*\*\*\*\***  
TNC MALE TO UHF FEMALE



**T230CU-X\*\*\*\*\***  
TNC MALE TO N FEMALE



**T225CU-X\*\*\*75**  
TNC MALE TO F FEMALE



**T258CU-X\*\*\*\*\***  
TNC FEMALE TO UHF MALE



**T251CU-X\*\*\*\*\***  
TNC FEMALE TO N MALE



**T232CU-X\*\*\*75**  
TNC FEMALE TO F MALE




**T227CU-X\*\*\*\*\***  
TNC FEMALE TO UHF FEMALE



**T253CU-X\*\*\*\*\***  
TNC FEMLAE TO N FEMALE



**T220CU-X\*\*\*75**  
TNC FEMALE TO F FEMALE



## BETWEEN SERIES TNC ADAPTERS (2)

### **T259CU-X\*\*\*50**

TNC MALE TO SMA MALE



### **T229CU-X\*\*\*50**

TNC MALE TO RCA MALE



### **T255CU-X\*\*\*50**

TNC MALE TO  
MINI UHF FEMALE



### **T261CU-X\*\*\*50**

TNC MALE TO SMA FEMALE



### **T231CU-X\*\*\*50**

TNC MALE TO RCA FEMALE



### **T254CU-X\*\*\*50**

TNC FEMALE TO  
MINI UHF MALE



### **T260CU-X\*\*\*50**

TNC FEMALE TO SMA MALE



### **T370CU-X\*\*\*50**

TNC FEMALE TO RCA MALE



### **MU572CU-X\*\*\*50**

MINI UHF FEMALE  
TO TNC FEMALE



### **T262CU-X\*\*\*50**

TNC FEMALE TO SMA FEMALE



### **MU573CU-X\*\*\*50**

MINI UHF MALE  
TO TNC FEMALE  
RIGHT ANGLE TYPE

